

# Sun and wind enclosure shades

*“ We are prepared to solve your most difficult and unusual applications.”  
FCI is dedicated to the design and manufacture of unique customer requirements.*



*“Large” Sun and Wind Protector with GF90 Remote Enclosure*

## Description

Sun and wind enclosure shades provide additional environmental protection in outdoor applications where constant heat, glaring sun and blowing sand challenge the placement and long-term reliability of remote electronic enclosures. The shades also prolong the life of optional LCD output displays.

The shade is a vented, hard anodized aluminum shell with foil backed polyurethane insulation and is pole mounted using stainless steel hardware.

## Industry Applications

- › Extreme outdoor environments
- › Design solar radiation temperature: 180°F [82°C]
- › Design wind velocity: 100 mph [45 mps]

## FCI Model Availability

### Large enclosure shade

- › GF Series gas mass flowmeter
- › MT Series multipoint mass flowmeter

### Small enclosure shade

- › ST98 FlexMASter Series flowmeter

## How To Order

Please contact your local FCI sales representative to configure the part number using the following OIS information:

- › For GF Series, select a “W” in Box 18 for GF90 or a “W” in Box 15 for GF92 and enter; “Large wind and sun shade”
- › For MT Series, select a “W” in Box 15 and enter; “Large wind and sun shade”
- › For ST98 Series, select a “W” in Box 7 and enter; “Small wind and sun shade”

## Other FCI proven custom product solutions include, but are not limited to:

- › Self-cleaning sensors
- › Quick disconnect sensors
- › Sensor coatings for corrosive processes
- › Custom extended sensor lengths
- › Custom process connections
- › Portable flowmeters
- › Self-calibrating flowmeters
- › Instrument programming/communications setup
- › Flow conditioning and extreme process evaluations

## Your local FCI Sales Representative is:



Web: [www.fluidcomponents.com](http://www.fluidcomponents.com) Email: [info@fluidcomponents.com](mailto:info@fluidcomponents.com)  
1755 La Costa Meadows Dr. San Marcos CA 92069 USA Phone: 760-744-6950 Toll free: 800.854.1993 Fax: 760.736.6250  
European Office: Persephonestraat 3-01, 5047 TT Tilburg, The Netherlands Phone: 31.13.5159989 Fax: 31-13-5799036  
**FCI is ISO 9001 certified/conformance to AS9000**